

Brodware

Floor mounted Bath Spout Installation Guide

*1.8007.03.0.XX, 1.8107.03.0.XX, 1.8107.04.0.XX,
1.9207.03.0.XX, 1.9307.03.0.XX, and 1.9707.03.0.XX Models*

NOTE FOR INSTALLER-

- Water proof up to the 1 / 2" BSP male thread water supply.
- To be installed by a licenced plumber.
- Ensure lines are flushed before fitment.

1) Install 1 / 2" BSP male thread water supply 15mm above the finished floor level. Screw the base flange onto the 1 / 2" BSP male thread. Apply thread sealant on the 1 / 2" BSP male thread, and screw down the quick disconnect fitting.

2) Place cover plate over the base flange. Push spout down onto quick disconnect fitting, and secure with grub screw provided.

3) If the floor is not level, the adjustment screws in the fixing flange can be adjusted to ensure the spout is level.

4) Check for leaks and functionality.

