

Brodware

1.7001.00.0.XX

32mm Plug and Waste Installation Guide

NOTE: This waste requires a hole size of $\text{Ø}42\text{-}46\text{mm}$ in the basin, and connects to a 32mm trap.

- 1) Unscrew the backing nut from the threaded waste body, and remove the bottom rubber seal.
- 2) Apply a flexible thread sealant and insert the top half of the waste into the hole in the basin.
- 3) From the underside of the basin, slide the bottom rubber seal over the thread of the waste until it is pressing against the bottom of the basin. Screw on the backing nut until it is compressing the rubber, and has created a seal. **DO NOT OVERTIGHTEN.** Connect waste trap.
- 4) Test for leaks and functionality.

