

# Brodware

1.7012.00.0.XX

## Basket Waste Installation Guide

NOTE: This waste requires a hole size of Ø90mm in the basin / sink.

1) Remove the plug from the waste. Unscrew the fixing screw from the waste assembly. Separate the top waste body and the waste collar, keeping the bottom rubber seal on the waste collar.

2) With the top foam seal still on the top waste body, insert it into the hole in the basin. Insert the fixing screw into top waste body.

3) From the underside of the basin, hold the waste collar with bottom rubber seal into position, and begin to screw the fixing screw into the waste collar. Continue screwing it together until it is compressing the rubbers, and has created a seal. **DO NOT OVERTIGHTEN.** Connect waste trap.

4) Insert the plug into the top of the waste.

5) Check for leaks and functionality.

