

Brodware

Shower Set Installation Guide

1.8023.04.0.XX, 1.9723.04.0.XX and 1.9723.06.0.XX

NOTE FOR INSTALLER:

- This shower has a top water inlet point.
- Water pressure must not exceed 500kpa.
- The flow restrictor (purple disc) and mesh filter must be used and installed at the water point, inside the brass push-on fitting supplied.
- Water lines must be thoroughly flushed before fitment.
- No liquid thread sealant to be used on this product.

ROUGH IN AND INSTALLATION PROCESS

- 1) Install the 1/2" BSP male thread water supply at the desired height, in relation to the spec sheet (found on our website). NOTE: this unit has a top feed water point.
- 2) Check water lines have been flushed prior to installation.
- 3) Ensure the riser section has been firmly screwed into the top tee junction of the shower roll.
- 3) Apply thread tape onto the male thread of the longer bend of the shower arm. Screw the male thread from the long bend of the arm into the top shower section of the shower. Make sure that the shower arm is positioned straight on the shower. ***IMPORTANT** * Make sure that no loose tape enters the tee, as this can interfere with the diverter function.
- 4) Ensure that the flow restrictor has been fitted to the inside of the quick disconnect fitting. The flow restrictor **MUST** be fitted at this point, and not at any other location on the shower. Ensure that there is no more than 10mm of 1/2" BSP male thread protruding out from the wall. Cut down the thread if required. Apply thread tape to the 1/2" BSP male thread, and screw the quick disconnect fitting firmly down to the finished face of the wall, with the flow restrictor and mesh filter inserted correctly.
- 5) Remove the trim and fixing bush from the bottom bracket. Reinsert the mounting bush and trial fit the shower into position on the wall. Mark your holes on the wall for drilling out the fixing holes. Remove the shower off the wall. Drill your fixing holes with a Ø6.0mm drill bit, and insert the star plugs.
- 6) Remove the fixing bush from the shower and secure to the wall using the fixing screws provided.
- 7) Fit the cover plate over the bottom fixing bush, and press the shower onto the quick disconnect fitting and the fixing bush. Secure the unit to the wall using the grub screws provided.
- 8) Fit off the hand piece, hose and over head shower rose.
- 9) Test the unit for functionality.

