

# Brodware

## Traditional Shower Arm and Rose Installation Guide

### IMPORTANT INFORMATION

- Refer to shower dimensions online to determine desired installation height
- Shower roses are flow restricted to 9 litres per minute
- Water line must be flushed prior to installation
- Water pressure to not exceed 500kpa, as per ASS3500
- Thread tape to be applied to G1/2" male thread on wall

